

Distribution Manifold for BBT Tanks

6 BBT Tanks 1050 hl

3 Lines: Inlet from Filter, Outlet to Bottle and Keg Filling

CO2 Recovery for all Tanks

38 Double-seat valves

9 Leakage Valves



Distribution Manifold BBT



Distribution Manifold BBT



Distribution Manifold BBT

